

51.2 V 100 AH 3U RACKMOUNT BATTERY (SELF-HEATING OR NOT)

OPERATION AND USER MANUAL



Legal Provisions

This manual describes in detail the requirements and procedures for safe installation and operation of lithium battery pack. Please read this manual carefully, only qualified persons are allowed to install, operate and maintain the system, otherwise it may cause product damage or personal safety risks.

Any actions against safety operation, or do not follow rules of this manual and limited warranty letter, will void warranty and qualification of this product. Meanwhile, the manufacturer will be not responsible for the product damage, property damage, personal injury or even death.

The information contained in this manual is accurate when it's issued. Manufacturer reserve right to change specification (such as optimization, upgrade or other operations) without prior notice, please always view the latest document via QR code. In addition, please noted that the diagrams/schematics in this document are used to help understand system configuration and installation instructions, which may be different from the actual items at the installation.

Legal Terms

Manufacturer will retain the copyright of this document, do not extract, copy or translate in any ways without the written permission.

Content

1. Information	1
1.1 Validity	1
1.2 Target Group	1
1.3 Levels of warning messages	1
1.4 Symbol Description	2
1.5 Abbreviation Description	3
2. Safety	5
2.1 Safety precautions	5
2.2 Safety instructions	5
2.2.1 Safety gear	6
2.2.2 Emergency safety measures	6
2.2.3 Other Tips	6
3. Product Overview	8
3.1 Introduction	8
3.2 Features	9
3.3 Specification	10
3.3.1 Dimension	10
3.3.2 Parameters	10
3.3.3 Panel Interface	11
3.4 Protection function	16
4 Installation	18
4.1 Preparation	18
4.1.1 Safety Compliance	18
4.1.2 Environment	18
4.1.3 Tools	18
4.2 Inspection	19
4.2.1 Unpacking	19
4.2.2 Scope of delivery	20
4.3 Start Installation	26
4.3.1 Remainder	26
4.3.2 Procedures	26
4.3.3 Tips	33
5. Cable connection and commissioning	34
5.1 Get battery ready	34
5.2 Grounding cable connection	34
5.3 Communication cable connection	25
5.4 DC power cable connection	25
5.5 Connecting with inverter	26
5.6 Commissioning	42
5.7 Switch off battery	42
6. Troubleshooting and FAQ	43
7. Transport, Storage	46

8. Disposal of battery	35
Appendix I	36

1. Information

1.1 Validity

This document is valid for: 51.2-100-R-3U-C Battery Pack and 51.2-100-R-H-3U-C Battery Pack.

1.2 Target Group

This document is intended for qualified persons and operators. Only qualified persons are allowed to perform the activities marked in this document with a warning symbol and the caption "Qualified person".

Qualified persons must have the following skills:

- Knowledge of how lithium iron phosphate batteries work and are operated.
- Knowledge of how an energy storage system (including PV/battery/hybrid inverter, MPPT, Meter, Distribution box etc.) works and is operated.
- Knowledge of local applicable connection requirements, standards, and directives.
- Training in the installation and commissioning of electrical devices, batteries.
- Training in how to deal with the dangers and risks associated with installing, repairing and using electrical devices, batteries.

1.3 Levels of warning messages

The following levels of warning messages may occur when handling the product

DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION









Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury or product permanent damage.




⚠ NOTICE

Indicates a situation which, if not avoided, can result in property damage or product not work or accelerated product damage



1.4 Symbol Description

1.4.1 Symbols on products label

Label	Definition
	Beware of electrical shock
	Do not place the battery within children/pet touchable area.
	Do not place the battery near heat source and flammable material
	Do not expose the battery to direct sunlight, rain and snow.
	Do not short circuit the battery
	The certificate label for Safety by TÜV Rheinland
	The UL1973 certificate label for Safety by Intertek
	The certificate label for European EMC directives

	The certificate label for U.K EMC directives
	Recycle label
	WEEE designation

1.4.2 Other symbols

Label	Definition
 Qualified person	Indicates activities that can only be performed by qualified persons
	Grounding point

1.5 Abbreviation Description

Abbreviation	Definition
Battery/battery pack/battery module	Single 51.2-100-R-3U-C rechargeable lithium iron phosphate battery pack including cells, BMS and enclosure etc.
Battery system/cluster	Multiple 51.2-100-R-3U-C battery pack connected in parallel with power, communication and grounding cables and installation auxiliaries.
BMS	Battery management system Electronical Unit to ensure lithium cells' safety and display information or control the battery work mode.
SOC	State of charge The battery state of charge refers to the percentage of the remaining capacity and rated capacity of the battery.
SOH	State of health The battery health status refers to the percentage between the full charged capacity and the rated capacity of the battery.
DIP switch	Dual in-line package switch
COCF	Charge over current protection
DOCP	Discharge over current protection
COVP	Cell over voltage protection

POVP	Pack over voltage protection
CHTP	Charge high temperature protection
DHTP	Discharge high temperature protection
CUVP	Cell under voltage protection
PUVP	Pack under voltage protection
CLTP	Charge high temperature protection
DLTP	Discharge high temperature protection
SCP	Short circuit protection

2. Safety

2.1 Safety precautions

DANGER

Explosion risk

- Do not impact the battery with heavy objects.
- Do not squeeze or pierce the battery pack.
- Do not throw the battery pack into the fire.

WARNING

Fire risk

- Do not expose the battery pack to the condition over 80°C.
- Do not put the battery near a heat source, such as a fireplace.
- Do not expose the battery pack to direct sunlight or raining.

CAUTION

Electric shock risk

- Do not allow non-qualified person to disassemble the battery pack.
- Do not touch the battery pack with wet hands.
- Do not expose the battery pack to moisture or liquid environment.

NOTICE

Damage risk

- Do not short-circuit or reverse connect the battery.
- Do not use chargers or charging devices unapproved by the manufacturer to charge the battery.
- Do not mix batteries from different manufacturers or different kinds, types or brands.

2.2 Safety instructions

The battery has been designed and tested in accordance with international (such as UL, IEC, UN38.3 etc.) safety requirements. However, due to various factors during the whole lifetime process, TOPBAND cannot

guarantee absolute safety, in order to prevent personal injury and property damage and ensure long-term operation of the battery, please do read the below section carefully to operate the battery and handle emergency situations.

2.2.1 Safety gear

It is required to wear the following safety gear when installing and handling the battery pack.



Insulated gloves



Safety Glasses



Safety Shoes

2.2.2 Emergency safety measures

Water invasion

Please cut off the AC power supply of the system first and then disconnect all switched under the premise of ensuring safety.

Electrolyte or gas leakage

If the battery pack leaks electrolyte, avoid contact with the leaking liquid or gas. If one is exposed to the leaked substance, immediately perform the actions described below.

- **Gas Inhalation:** Evacuate the people in the contaminated area and seek medical aid immediately.
- **Eye Contact:** Flush your eye with clean and flowing water for 15 min, and seek medical aid immediately.
- **Skin Contact:** Thoroughly rinse the exposed area with soap and water to be sure no chemical or soap is left on them, and seek medical aid immediately.
- **Ingestion:** Induce vomiting, and seek medical help immediately.

⚠ WARNING

In case of fire situations, please use carbon dioxide fire extinguisher rather than liquid to put out fires.

2.2.3 Other Tips


- All the product are strictly inspected before shipment, please contact your supplier for replacement if you notice there's any defectives such as swelling.
- Do not disassemble batteries and components, otherwise the manufacturer will not be responsible for any damage caused by unauthorized disassembly or repair.

- Do enable the battery to be safely grounded before use to make sure the system in safe and normal operation.
- Please ensure that the electric parameters of these devices are compatible mutually before connecting the battery to other devices.
- Please take the environmental factors into careful considerations to ensure that the system can work in a suitable condition as the environment and storage methods have a certain impact on the service life and reliability of this product.


3. Product Overview

3.1 Introduction

The 51.2-100-R-3U-C battery and the 51.2-100-R-H-3U-C battery are designed for residential applications and function as storage units in photovoltaic systems. They are 51.2V lithium battery systems with a built-in BMS. They can operate in on-grid, backup, and off-grid modes with compatible inverters. Below is the general schematic of an AC-coupled system with the batteries.



Another scenario is that after the inverter is connected to the battery through communication, the battery can also be connected to VICTRON cerbo GX VE.can through CAN communication.



⚠ CAUTION


This electrical connection in this diagram is only for illustration, please follow the Manual suggestions of related devices and operate in accordance with locally applicable connection requirements, standards, and directives.

3.2 Features

- Highest safety, battery is made from LiFePO₄ chemistry and comply with highest international safety and transport standard.
- Modular and flexible, support up to 32 batteries connect together to expand the system energy.
- Built-in pre-charge circuit to avoid rush current when connecting with different inverter/chargers.
- Automatic dynamic addressing function when connected multiple batteries together.
- Support a maximum of 100% DOD under off-grid and back-up application
- Built in BMS provide warning and protection functions including over-discharged, over-charged, over-current, short-circuit and high/low temperature.
- LiFePO₄ as cathode material and automatic balancing function to meet longer cycle life
- Compact size and light weight for easy installation and maintenance.
- Multiple installation bracket to adopt with different customers' requirement.
- LED display, CAN/RS485 port for external communication and upgrade the BMS firmware.
- Rapid shut down function for North American market.

3.3 Specification

3.3.1 Dimension



3.3.2 Parameters


Items	51.2-100-R-3U-C
Rated voltage	51.2V
Max. voltage range	44.8~57.6V, Shipping voltage>51.2V
Charge voltage	56.0V
Float charge voltage	54.6V
Nominal energy@0.2C	5.12KWh
Usable energy@0.2C	5.12kWh
Nominal capacity@0.2C	100Ah
Dimension	482*133.5*460mm (18.9*5.2*18.1 inch)
Weight	~46kg (101lb)
Standard charge current	≤50A
Max. charge current	70A
Standard discharge current	≤50A
Max. discharge current	100A (initial temp. ≤30℃)
Peak discharge current	101~119A@5mins 120~200A@15S
Communication	RS485 /CAN

Max parallel number	32pcs	
Operation temperature ¹	Charge: -5~50℃ Discharge:-10~50℃	
Storage temperature @off mode	0℃ <T<30℃	<6 months
	-10℃ <T<45℃	<3 months
	Recommended environment	15~35℃ , 5~75%RH

⚠ NOTICE

The optimum operating temperature range is from 15°C to 30°C, Frequent exposure to the harsh temperatures may worsen the performance of the battery pack and cycle life.

3.3.3 Panel Interface



No.	Items	Usage description	Remark
A	Handles	For handling, intallation and disassembly of battery	
B	Grounding	Used to connect battery with ground	
C	Positive terminal	Used to connect the inverter/charger	
D	Circuit breaker	Automatically disconnect when the current is too high	
E	Reset	Used to sleep(3s)/awake(3s)/reset(6~10s) BMS in power on mode.	
F	M/S	Used to indicate the module is Master or Slave battery	Single mode: OFF Parallel mode: ON- Master battery OFF-Slave battery
G	RUN	Used to show battery is in running status when lighting or	

		flashing	
H	ALM	Used to show battery Alarm/Protection status	
I	DIP	Used to set the RS485 baud rate and inverter protocol choosing	
J	SOC	Used to show battery real-time SOC	
K	Dry contact	1 channel input signal 2 channels output signal	
L	RS485/CAN	For external communication	
M	Link IN Link OUT	For internal communication	
N	Power switch	Used to Power on/off battery	
O	Negative terminal	Used to connect the inverter/charger	
P	Mounting ear	Used to fix with rack or cabinet	

3.3.3.1 D: Dry contact

PIN	Type
1	NO Output1, Charge enable/disable passive signal
2	
3	NO Output2, discharge enable/disable passive signal
4	
5	Passive NO INPUT signal, connecting to Master when parallel connection. Rapid Shut Down function for US market
6	

3.3.3.2 G: RS485 / CAN

Port	Pin No.	Definition	Remarks
RS485	1	RS485-B1	Used for external RS485 communication
	2	RS485-A1	
	3	SGND	
	4	/	
	5	/	
	6	SGND	
	7	RS485-A1	
	8	RS485-B1	
CAN	1	/	Used for external CAN communication
	2	/	
	3	SGND	
	4	CAN-H	
	5	CAN-L	
	6	SGND	
	7	/	
	8	/	









3.3.3.3: DIP addressing






DIP						
RS485 baud rate	RS485 Connect		Undefined		CANbus Connection	
1	2	3	4	5	6	7
ON: 115200	0	0	Reserved for multiple cluster parallel and other future function		0	0
OFF: 9600	0	0			1	0
	0	0			0	1
	1	0			0	0
	1	0			1	0
	1	0			0	1
	0	1			0	0
	0	1			1	0
	0	1			0	1
Keep all batteries the same setting	Master: according to inverter brand Slave: keep default setting		Keep default setting		Master: according to inverter brand Slave: keep default setting	

Note:

Only master battery needs to set the Protocol ID, keep all slave battery default setting, after choose the protocol ID, the battery will auto detect the inverter information and corresponding to get into running, restart to take effect after setting new DIP sequence.

RS485 Connection		CANbus Connection		DIP setting (Master battery)
Protocol ID	Inverter	Protocol ID	Inverter	







0	Voltronic/MPP/Alpha outback/Phocos/Kodak	0	Victron/SMA/ Studer Innotec/Sofar	 X000000
0	Voltronic/MPP/Alpha outback/Phocos/Kodak	1	SolArk/Solis/Goodwe /Deye/Growatt/SAJ/Meg arevo/INVT/Sermatec/ MUST/Sunsynk	 X000010
0	Voltronic/MPP/Alpha outback/Phocos/Kodak	2	Schneider	 X000001
0	Voltronic/MPP/Alpha outback/Phocos/Kodak	3	LUX power	 X000011
1	Sol-Ark /SRNE	0	Victron/SMA/ Studer Innotec/Sofar	 X100000
1	Sol-Ark /SRNE	1	SolArk/Solis/Goodwe /Deye/Growatt/SAJ/Meg arevo/INVT/Sermatec/ MUST/Sunsynk	 X100010
1	Sol-Ark /SRNE	2	Schneider	 X100001
1	Sol-Ark /SRNE	3	LUX power	 X100011

2	LUX power	0	Victron/SMA/ Studer Innotec/Sofar	 X010000
2	LUX power	1	SolArk/Solis/Goodwe /Deye/Growatt/SAJ/Meg arevo/INVT/Sermatec/ MUST/Sunsynk	 X010010
2	LUX power	2	Schneider	 X010001
2	LUX power	3	LUX power	 X010011
3	Schneider	0	Victron/SMA/ Studer Innotec/Sofar	 X110000

NOTICE

Fail to follow the DIP switch setting will cause the communication fault between battery and inverter, for more detail setting with different inverter/charger, please contact your supplier for consultation.

3.3.3.4 RUN/ALM/SOC

Mode	Status	RUN	ALM	LED indicator				Description
								
Power off	-	OFF	OFF	OFF	OFF	OFF	OFF	All OFF
Standby	Normal	FLASH1	OFF	According to battery SOC				See note
	Warning	FLASH1	FLASH3					
Charge	Normal	ON	OFF	According to battery SOC (highest SOC LED: FLASH2)				See note
	Warning	ON	FLASH3					
	COCP	FLASH1	OFF	According to battery SOC				Stop charging
Discharge	Normal	FLASH3	OFF	According to battery SOC				See note

	Warning	FLASH3	FLASH3					
	CUVP/PUVP	OFF	FLASH3	OFF	OFF	OFF	OFF	Stop discharging
	DOCP	OFF	ON	OFF	OFF	OFF	OFF	Stop discharging
Temperature	CHTP/DHTP CLTP/DLTP	OFF	ON	OFF	OFF	OFF	OFF	Stop charging/discharging
Failure	Cell/NTC failure Sensor failure MOS failure Reversed polarity /SCP	OFF	ON	OFF	OFF	OFF	OFF	Stop charging/discharging

Note: 'Warning' including items of cell imbalanced/low voltage/high current/high&low temperature.

FLASH Type	ON	OFF
FLASH1	0.25S	3.75S
FLASH2	0.5S	0.5S
FLASH3	0.5S	1.5S

3.4 Protection function

Items	Description	Remark
Charge end COVP POVP	The BMS will stop charging if any cell or PACK voltage reach the protection value and it will be auto-released only when both Pack and cell voltage back to the release voltage range or there is efficient discharge current.	
Discharge end CUVP PUVP	The BMS will stop discharging if any cell or PACK voltage is under the protection value and it will be released only when all the cell voltage back to the release voltage range or there is efficient charge current.	Can Automatic recovery. Please charge timely, otherwise it may be in Low-power mode to be over-discharged and damage battery.
CHTP DHTP	The BMS will stop charging or discharging or both if any cell/environment/MOS temperature is beyond the range.	Automatic recovery when temperature falls.
CLTP DLTP	The BMS will stop charging or discharging or both if any cell/environment/MOS temperature is under the range.	Automatic recovery when temperature rise.
COCP	The BMS will stop charging when the charging current is higher than the protection value. And it will release from the protection	Automatic recovery. If locked after three

	when the system delays time is met.	consecutive times, manual intervention is required.
DOCP	The BMS will stop discharging when the discharging current is higher than the protection value. And it will release from the protection when the system delays time is met	Automatic recovery. If locked after three consecutive times, manual intervention is required.
SCP Reversed polarity	The BMS will stop charging when detect short circuit or reversed polarity.	Charge to release. Manual press reset.
Temperature, Voltage, Current sensor failure	Enter the failure mode, manual intervention is required no charging and discharging.	Manual intervention.
Sleep mode	After reaching a certain condition, BMS will enter dormancy mode to reduce BMS consumption	Charge, press reset or restart to activate.

CAUTION

Please re-charge the battery via MPPT, grid/generator or other energy source within 24h if the battery is over discharged, otherwise, it may be damaged.

NOTICE

Manually short-circuit and reverse the battery will void the warranty.

4 Installation

4.1 Preparation

4.1.1 Safety Compliance



The system installation must be finished by qualified person(s). During the whole installation process, please strictly follow the local safety regulations and related operating procedures.










4.1.2 Environment

The operating environment shall meet the following requirements:

Category	Description
Working temperature	0℃ -50℃ (maximum operating range) 15℃ -30℃ (optimal temperature)
Relative humidity	5%~90%, No condensation
Altitude	<3000m
Safety requirement	<ul style="list-style-type: none"> Do not expose the battery to direct sunlight, rain and snow. Do not place the battery within children/pet touchable area. Do not place the battery near heat source and flammable material Do not drop, deform, impact, cut or spearing with a sharp object. Do not put heavy things on battery. Do not disassemble the battery without Manufacturer's permission. No conductive dust and water or other liquid to contact battery. Follow the emergency measure if there is water invasion or electrolyte and gas leakage. Contact your supplier within 24 hours if any product failure happens.

4.1.3 Tools

Tools	
Torque screwdriver 	Multi-meter 

<p>Torque wrench</p> 	<p>Cable crimper</p> 
<p>Wire stripper</p> 	<p>Tape measure</p> 
<p>Flat-head screwdriver</p> 	<p>Phillips-head screwdriver</p> 
<p>Wire stripper</p> 	<p>Drill</p> 
<p>Phillips-screwdriver bit</p> 	

4.2 Inspection




4.2.1 Unpacking









- Please load and unload it in accordance with the specified requirements to prevent sun and rain when you receive the equipment.
- Please check and confirm the goods (such as quantity, appearance, etc.) according to the "scope of delivery " before unpacking.






- Do light take and put during unpacking process to protect the surface coating of the object;
- Please record and feedback to the manufacturer if the inner packing is damaged after unpacking.







4.2.2 Scope of delivery





Check the scope of delivery for completeness and any externally visible damage. Contact your supplier for supplementary delivery if the listed material is incomplete or damaged.







General materials		
<i>(Battery unit)</i>		
<div>   </div>		
<div> Battery Pack *1pcs Manual *1pcs </div>		
Optional materials		
<i>(Noted that each pack unit together with one type bracket as default)</i>		
Mounted kits Type	Material detail	Qty.
Stack mounted kits (Packing using separately carton, 2 battery packs)	A: Stacking components 	8pcs
	B: Head screw M4	32pcs
	C: Battery to battery parallel Soft copper busbar	2pcs


Stack mounted kits (Packing using separately carton, 4 battery packs)		
	D: Battery to battery grounding cable(300mm)  	2pcs
	E: Battery to battery communication cable 	1pcs
	A: Stacking components 	16pcs
	B: Head screw M4	64pcs
	C: Battery to battery parallel Soft copper busbar 	2pcs
	D: Battery to battery grounding cable(300mm)  	4pcs
	E: Battery to battery communication cable	3pcs

		
Floor mounted kits (Packing using separately carton, 2 battery packs)	A : : Outer hexagon combination bolt	4pcs
	B:Cross recessed small countersunk head screws	28pcs
	C:Side Fixing parts 	2pcs
	D: Battery to battery parallel Soft copper busbar 	2pcs
	E: Battery to battery grounding cable 	2pcs
	F: Battery to battery communication cable 	1pcs
	G: Base	1pcs

		
	H:Decorative panel 	1pcs
	I: Side fixing parts between two units 	4pcs
	J: Expansion bolt M6*50	6pcs
Wall mounted kits (Packing using separately carton, 2 battery packs)	A:Base 	1PCS
	B:Left wall hanging bracket 	1PCS
	C:Right wall hanging bracket 	1PCS

	<p>D:Side fixing parts between two units and the base</p> 	2PCS
	<p>E:Decorative panel</p> 	1PCS
	<p>F:Side Fixing parts</p> 	2PCS
	<p>G:Side fixing parts between two units</p> 	2PCS

	<p>H:Expansion bolt M10*80</p> 	<p>6PCS</p>
	<p>I:Expansion bolt M6*50</p> 	<p>2PCS</p>
	<p>J:M6*16</p> 	<p>2PCS</p>
	<p>K:Head screw M4</p> 	<p>26PCS</p>
	<p>L:M4*12</p>	<p>8PCS</p>
	<p>M:Battery to battery grounding cable</p> 	<p>2PCS</p>
	<p>N:Battery to battery communication cable</p> 	

	O:Battery to battery parallel Soft copper busbar	
		

4.3 Start Installation



4.3.1 Remainder

Please check again the following conditions or equipment whether meet the requirements before installation:

- Check if there's enough space for installation, and if the load-bearing capacity of the bracket or cabinet meets the weight requirements.
- Check whether the power cable pair(s) used meets the maximum current requirement for operation.
- Check whether the overall layout of power supply equipment and batteries at the construction site is reasonable.
- Check whether the installer is wearing anti-static wristband.
- Check whether there're two people on the construction site for installation work.
- Check if there's potential risks at location of installation site, e.g flooding, sun exposure, corrosion, and salt spray.

4.3.2 Procedures

⚠ CAUTION

Injuries may result if the product is lifted incorrectly or dropped while being transported or mounted.
Wear suitable personal protective equipment for all work on the product.





⚠ CAUTION


Ensure that no lines are laid in the wall which could be damaged when drilling holes.

4.3.2.1 Rack mounted

i.	Take the battery pack out from carton.
ii.	Get the Rack or cabinet ready and place it horizontally at a reasonable location.
iii.	Place the battery on the rack or cabinet tray via manual-lift, Insert the screws and fasten the battery to the rack or cabinet.
iv.	Finish the cable connection



4.3.2.2 Stack mounted


i.	Take the battery pack out from carton.	
ii.	Remove the mounting ear from both side of the battery.	
iii.	Install the stacking component at four corners of the battery.	
iv.	Remove the hook on the stacking component of the bottom battery of each stack.	
v.	Put another battery on top of the previous module, and align the locating holes and connect the 4 lockers together.	

<p>vi. The maximum number in each stack is 4 modules.</p> <p>vii. Finish the cable connection</p>	
---	---


Note: Do not stack the batteries directly.

4.3.2.1 Floor mounted




<p>1. Place the base against the wall on the ground and drill holes according to the position.</p>	
--	--


2. Fix the wall bracket onto the battery.




3. Place two batteries on the base and secure the wall bracket




4. Install the battery mounting bracket.




5. Secure the decorative cover plate lock.




6. The installation is completed.




4.3.2.1 Wall mounted






1. Drill holes on the wall according to the dimensions in the picture



2. Fix the wall mounting bracket to the wall.






<p>3. Place the battery on the wall mount bracket.</p>	
<p>4. Fix the side fixing piece between the battery and the wall.</p>	
<p>5. Secure the decorative cover plate lock.</p>	

6. The bracket installation is completed.





4.3.3 Tips

4.3.3.1 Installation not allowed

Direct upside down	Left side flip	Right side flip
 <p style="text-align: center; color: red; font-size: 2em;">X</p>	 <p style="text-align: center; color: red; font-size: 2em;">X</p>	 <p style="text-align: center; color: red; font-size: 2em;">X</p>

4.3.3.2 Other Installation

Hang on the wall with Holder	Placing on the desk
 <p>Please make sure the holder can handle a minimum weight of 50kg</p>	 <p>Please make sure the desk can bear the total weight.</p>

! NOTICE

ANY others installations, please avoid the battery directly contacting the ground and avoid of high salinity, humidity to prevent the product from rusting and corrosion.

5. Cable connection and commissioning

! Qualified person

5.1 Get battery ready

5.1.1 Ensure all the battery is in OFF mode, check and confirm the installation is tighten and stable.

5.1.2 Check the number and specification of cable kit accessories are correct according to the Scope of delivery item, if you are making cable yourself, please follow manufacturer's requirements.


5.1.3 Switch on all battery individually before wiring, check whether there is any alarm/protection information, if yes, turns to troubleshooting. Then switch off all batteries.

5.2 Grounding cable connection

5.2.1 Take out the grounding screw on the battery panel, and get the cable conductor through it.

5.2.2 Fix them together, with a cylinder screwdriver and tighten it.


5.2.3 Connect the grounding cable with next battery module.



5.3 Communication cable connection

5.3.1 Take out battery to battery communication cable.

5.3.2 Confirm the location of Master battery, insert the RJ45 plug into the BATTERY COMM OUT port and connect the other side to next battery BATTERY COMM IN port, daisy chained all batteries.



Note: the module with empty BATTERY COMM IN port is Master battery

⚠ NOTICE

The BMS inside the battery pack will automatically terminate BOTH end of CANBUS pins, DO NOT need to plug the 120Ω terminator again.


5.4 DC power cable connection

5.4.1 Take out Battery to battery parallel Soft copper busbar.

5.4.2 Open the battery terminal cover.

5.4.3 Lock the M10 screw onto the Soft copper busbar.

5.4.4 Close the terminal cover.



5.5 Connecting with inverter

⚠ CAUTION

Confirm inverter AC input and PV input is disconnected before wiring connection, and the DC/ signal switch of inverter/charger is in off status.

5.5.1 Connecting Master battery Link IN port with inverter CAN or RS485 communication port via inverter communication cable (*Version I/II/III or customized*).

5.5.2 Connecting battery OUTPUT (+) with inverter battery INPUT (+), battery OUTPUT (-) with inverter battery INPUT (-), an external disconnection breaker between battery system and inverter is recommended, choose the corresponding power cable pair and wiring them correctly.


Note:



! NOTICE

Choose the suitable disconnection breaker considering the inverter power/current, rated voltage, tripping characteristic etc.


Wiring diagram allowed:

i. Single pair cable wiring----100A, 5KW rating







ii. **Double pairs cable wiring----***200A, 10KW rating*



iii. Multiple pairs cable wiring-----400A, 20KW rating




iv. Multiple towers and inverters cable wiring



Considering system stability, when you install multiple batteries, please always keep a certain capacity margin of 30~50%. It is recommended to configure the inverter capacity with battery energy in 1: 2 proportion, for instance, if you have a 5KW rated inverter, connect 2 pieces(10KWh) or more batteries.

Wiring diagram not allowed:



⚠ NOTICE

The maximum communication cable length is required to be less than 15m between inverter/charge and battery.

The maximum power cable length is suggested to be less than 10m between inverter/charge and battery.

⚠ CAUTION

Maximum current tolerance per terminal is 400A, 300A is recommended for continuous use, use the appropriate number of power cable pairs for the site configuration and local connection requirements, standards and directives.

5.6 Commissioning

5.6.1 Set the DIP address of the Master battery (and the Slave battery if there is any RS485 baud rate changed).

5.6.2 Switch on all battery modules, wait for 10s, make sure that only M/S led is on Master battery .Then turn off the battery switch.

5.6.3 Turn on the circuit breaker on the battery.

5.6.4 Turn on the breaker between the inverter and battery if there is any, then turn on the inverter/charger isolator. Finally, turn on the battery switch again. (The pre-charge function will only take effect when the battery is started when all switches in the battery circuit are closed.)

5.6.5 Finish the setting on inverter/charger or any other control devices, if everything is correct, you are ready to use the system.

No.	Inverter setting parameters	Detail
1	Absorption voltage	56.0V
2	Float voltage	54.6V
3	Re-charge/Generator start voltage	$\geq 50V$
4	Re-start voltage	52V
3	Low SOC limit (Grid-tied)	10/20% (differ from inverter brand)
5	Low SOC cut-off (Off-grid)	4%
6	Low Voltage cut-off	48.0V
7	Rated charging current limited value	50A*N (N is the Quantity of the battery pack)
8	Rated discharging current limited value	50A*N (N is the Quantity of the battery pack)
9	Max. charging current limited value	70A*N (N is the Quantity of the battery pack)
10	Max. discharging current limited value	100A*N (N is the Quantity of the battery pack)
11	Force charge/ Activate	Enable

For more information to connect with different inverter/charger, please contact your supplier for technical support.

CAUTION

If your system is a back-up or off-grid system, make sure your configuration can cover the worst situation to avoid battery to be over-discharged.

5.7 Switch off battery

5.7.1 Turn off the inverter.

5.7.2 Turn off the disconnection breaker if there is any.

5.7.3 *Turn off all batteries signal switch.*

6. Troubleshooting and FAQ

Items	Solution	Measure
Unable to start	<ol style="list-style-type: none"> 1. Power on battery and press RESET 6s to observe whether the battery can be started. 2. Charge the battery use a charger or inverter to provide 54~57.6V voltage and observe it can be started. 	<p>If the abnormal status still alive after above steps, please contact your supplier.</p> <p>If there is any other situation(s) excluding in this table, turn off the fault battery, contact your supplier.</p>
Unable to charge	<ol style="list-style-type: none"> 1. Check whether the cable connection between the battery and the inverter/charger is correct. 2. Check whether the inverter/charger setting is correct. 3. Check whether the battery is in charge protection mode, if yes, try to discharge the battery. 	
Unable to discharge	<ol style="list-style-type: none"> 1. Check whether the cable connection between the battery and the inverter/charger is correct 2. Check whether the battery occurs short circuit, reverse connection, pre-charge failure during connection inverter etc. 3. Check whether the battery is in discharge protection mode, if yes, try to charge the battery. 	
High/Low temperature	<ol style="list-style-type: none"> 1. Stop the battery system for a while, check whether the installation location temperature meet the requirement. 2. Avoid continuous full charging and discharging. 	
High current	Check the configuration and parameters setting on the inverter/charger is correct.	
ALM always on	<ol style="list-style-type: none"> 1. Check the fault information on the inverter APP or display if possible. 2. Ask your supplier to offer BMS monitoring software to locate the reason and back to them for solution. 	
Communication fail	<ol style="list-style-type: none"> 1. Check the communication cable type is correct and is contacted well. 2. Check the DIP switch setting is correct. 3. Check the inverter protocol related setting is correct. 4. Check both battery and inverter are working properly. 	

Q1: Battery maximum SOC is 98~99% and never goes to 100%SOC during daily cycle use, why?

This is normal and have no influence on capacity, usually BMS will calibrate the SOC to 100% when reached cut-off current or trigger HVP, however, to avoid battery from being overcharged and to extend the cycle life as longer as possible, we left a room and set a charging profile to let battery charge slowly near full, please float the battery about 0.5~1 hour to calibrate the SOC.

Q2: 'High voltage' and 'cell unbalance' warning and alarm in rare cases, does it mean battery is

damaged?

No. This is not unusual and happened on new batteries that are not balanced yet, please lower the maximum charge voltage (54.6V) and float the battery via grid or generator. If not solved, please contact your supplier.

Q3: When having multiple batteries in parallel connection, the battery on the end can't be fully charged.

Pay attention to your wiring diagram, please always follow the manual wiring advises and choose proper cable size and pair.

Q4: The current is 0A when connecting with a very small load at the situation that having multiple batteries in parallel connection, how to solve it?

Each BMS has a threshold current of 0.5A (~25W) before it begins to report, this leads the inaccurate display of the current.

Q5: SOC is not accurate or suddenly jumps to 100% during charging.

This mostly happen in off-grid applications on batteries that have not been calibrated SOC for a long time or situations that are similar to Q4 that with inverter in Idle mode or a small DC load or store the battery for a long time, we suggest fully charging at once the batteries per month refer to Q1.

Q6: The system is still running when the inverter log shows 'internal failure' Warning.

This is our logic and this warning flag indicates there is 1 or more module(s) is in communication offline from the system, the system will derating and until communication is recovered.

Q7: Inverter pulling power from Grid to charge batteries in self-consumption mode.

When reached certain conditions such as low state of charge etc., battery will send charge request to ask inverter to charge the batteries, to avoid this, please discharge DOD as manual suggested.

7. Transport, Storage


- Do not violently shake, impact or squeeze, and prevent sun and rain during the transportation.
- Do light take and put and strictly prevent falling, rolling, and heavy pressure during loading and unloading.
- The battery should be placed in a dry, clean, dark, and well-ventilated indoor environment for long-term storage, and the recommended storage temperature range is 15~30℃ .
- No harmful gases, flammable and explosive products and corrosive chemical substances in the storage location.
- The batteries should be stored and transported in close to 50% SOC, do not store over 80%SOC for long time.
- If do not use for a long time, the battery needs to be charged every 6 months.
- No fall down, no pile up over 6 layers, and keep face up.

8. Disposal of battery


Disposal of battery must comply with the local applicable disposal regulations for electronic waste and used batteries, please review your local Battery recycling or management regulations or contact your supplier for more information.

Appendix I


Connect with Victron GX & inverter/charger




Connect with SMA inverter/charger




Connect with Schneider inverter/charger




Connect with Studer inverter/charger




Connect with GOODWE hybrid inverter




Connect with Sol-Ark hybrid inverter




Connect with Growatt inverter




Connect with Solis inverter




Connect with Deye hybrid inverter




Connect with Megarevo/INVT inverter




Connect with LUX SNA series inverter




Connect with LUX LXP series inverter




Connect with Alpha & Outback energy inverter




Connect with Voltronic inverter



Connect with Phocos inverter



Connect with LUX power inverter



⚠ NOTICE

Keep the unused cable pins NULL to avoid affecting the closed loop communication.

⚠ NOTICE

A ground connection of communication cable may be required from some inverters, please follow the rules from inverter manufacture.


INTEGRATION GUIDE

Sol-Ark

Inverter PIN CONFIGURATIONS OF “BATTERY CANBUS” PORT FOR MODBUS & CAN BUS PROTOCOLS


Pin	Battery CAN Bus Port	
	Modbus	CAN Bus
1	RS-485 A+	--
2	RS-485 B-	--
3	--	--
4	--	CAN Hi
5	--	CAN Lo
6	GND	GND
7	RS485 A+	--
8	RS485 B-	--

Connection method of CAN communication line:




Battery CAN port	Sol-Ark CAN	Cable suggest
Pin4	Pin4	Version-II(CAN)
Pin5	Pin5	
Pin6 (optional)	Pin6 -outdoor Pin2 –indoor (optional)	

CAN communication Battery DIP selection :




When use CAN communication,protocol Number into Sol-Ark is :00

Connection method of RS485 communication line:



Battery RS485 port	Sol-Ark 485	Cable suggest
Pin1 485B	Pin8 485B	
Pin2 485A	Pin7 485A	

RS485 communication Battery DIP selection :




When use RS485 communication,protocol Number into Sol-Ark is :05

Lux POWER

Inverter PIN CONFIGURATIONS OF “BATTERY CANBUS” PORT FOR MODBUS & CAN BUS PROTOCOLS

LXP8K 10K 12K



Pin	Description
1	NC
2	GND
3	NC
4	BAT CAN H
5	BAT CAN L
6	NC
7	BAT RS485 A
8	BAT RS485 B




SNA 6K

Pin	RS 485 port
1	RS 485B
2	RS 485A
3	---
4	---
5	---
6/7/8	---

Connection method of RS485 communication line:



RS485 communication Battery DIP selection :




When use RS485 communication, protocol Number into LUX is :6


Other connections

1) Lux CAN + RS485 Windows Upper Software


Connection method of CAN/RS485 communication line:



CAN communication Battery DIP selection :




When use CAN communication protocol Number into LUX is :6




2) Lux in RS485 + Victron CAN.

Connection method of CAN/RS485 communication line:



communication Battery DIP selection :




VICTRON


Inverter PIN CONFIGURATIONS OF “BATTERY CANBUS” PORT FOR MODBUS & CAN BUS PROTOCOLS

Victron VE.Can pin# a	
1	NC
2	NC
3	NET-C (V-)
4	NC
5	NC
6	NET-S (V+)
7	CAN-H
8	CAN-L

Connection method of CAN communication line:



CAN communication Battery DIP selection :




The protocol number for selecting the victron during CAN communication is : 500K

Schneider CAN

Inverter PIN CONFIGURATIONS OF "BATTERY CANBUS" PORT FOR MODBUS & CAN BUS PROTOCOLS




Battery CAN port	Conext Gateway	Cable suggest
Pin4	Pin12	customized
Pin5	Pin10	



Item
1 Power port
2 Xanbus port
3 Ethernet port
4 12-pin port (see 12-Pin Connector Pinouts)
5 USB port
6 Power button
7 The "I" in InsightHome is an LED indicator used for signaling device status.



LED	STATE	Description
Green	Solid	The InsightHome is powered on.
Green	Blink	Device is booting up or logging data to internal memory when flashing.
Orange	Solid	Devices on the Power system have events to report.

1 Digital output (0-40VDC)	3 GND	5 Do Not Connect
7 GND ISO	9 RS485 A ISO	11 RS485 B ISO




2 Digital input 1 (12VDC)	4 Digital input 2 (12VDC)	6 Do Not Connect
8 GND ISO	10 CAN L ISO	12 CAN H ISO

CAN communication Battery DIP selection :



Battery CAN port	Conext Gateway	Cable suggest
Pin4	Pin12	customized
Pin5	Pin10	



TO inverter RS485 port




Schneider RS485

Inverter PIN CONFIGURATIONS OF "BATTERY CANBUS" PORT FOR MODBUS & CAN BUS PROTOCOLS




Battery RS485 port	InsightHome	Cable suggest
Pin1 RS485 B	Pin11 RS485 B	customized
Pin2 RS485 A	Pin9 RS485 A	



Item
1 Power port
2 Xanbus port
3 Ethernet port
4 12-pin port (see 12-Pin Connector Pinouts)
5 USB port
6 Power button
7 The "I" in InsightHome is an LED indicator used for signaling device status.



LED	STATE	Description
Green	Solid	The InsightHome is powered on.
Green	Blink	Device is booting up or logging data to internal memory when flashing.
Orange	Solid	Devices on the Power system have events to report.

1 Digital output (0-40VDC)	3 GND	5 Do Not Connect
7 GND ISO	9 RS485 A ISO	11 RS485 B ISO




2 Digital input 1 (12VDC)	4 Digital input 2 (12VDC)	6 Do Not Connect
8 GND ISO	10 CAN L ISO	12 CAN H ISO

RS485 communication Battery DIP selection :



Battery RS485 port	InsightHome	Cable suggest
Pin1 RS485 B	Pin11 RS485 B	customized
Pin2 RS485 A	Pin9 RS485 A	

TO InsightHome Pin9 and Pin11




TO inverter RS485 port




SRNE RS485

Inverter PIN CONFIGURATIONS OF “BATTERY CANBUS” PORT FOR MODBUS & CAN BUS PROTOCOLS



RS485 communication Battery DIP selection :



Inverter select 33, select WOW

33	BMS communication	When item 32 is set to 485 or CAN, the corresponding communication protocol must be selected in item 33
		PAC=PACE, RDA=Ritar, AOG=ALLGRAND BATTERY, OLT=OLITER, HWD=SUNWODA, DAQ=DAKING, WOW=SRNE, PYL=PYLONTECH UOL=WEILAN